



Audio Intelligent Vinyl Solutions

•Bringing You Closer To The Music•

www.audiointelligent.com

info@audiointelligent.com

573-696-3551

Basic Directions For Everyday Machine Cleaning Using the Audio Intelligent Vinyl Solutions 3-Step Record Cleaning Process and the Premium One-Step Formula No. 6 Product

1. Carefully remove loose dust and debris with a soft brush, compressed air, or by simply rinsing with cool tap water and then patting the record dry with a cotton towel. Do not use a microfiber towel as it will produce lint that is small enough to enter the record groove.
2. Apply enough **Enzymatic Formula** to completely cover the surface of the record. A little trial and error will help in determining just how much fluid should be applied.
3. Using a rounded- or blunt-bristle nylon brush (we recommend our **Listener Select Record Cleaning Brush**) or cloth pad brush, carefully spread the **Enzymatic Formula** over the entire surface of the record. Add more fluid as necessary to completely cover the surface of the record. If fluid sloshes over the edge of the record you have applied more than is necessary. This is most easily done while the record is spinning on a vacuum record cleaning machine.
4. Gently apply a very slight pressure with the brush to the surface of the record. **DO NOT APPLY HARD PRESSURE AS THIS CAN COMPACT DEBRIS INTO THE RECORD GROOVES, MAKING THE CLEANING PROCESS MORE DIFFICULT AND CAN CAUSE PERMANENT DAMAGE TO THE RECORD!** Continue brushing for 1 to 3 minutes, agitating the fluid on the record and allowing the enzymatic content of the formula to loosen and dissolve the contaminants on the record.
5. Thoroughly vacuum the record.
6. Repeat this process using either the **Super Cleaner Formula** or the **Premium Archivist Formula** as the second cleaning step. Use a separate brush to avoid cross-contamination and mixing of the separate formulas.
7. For a final cleaning step, use the **Ultra-Pure Water** product with a separate brush, following the procedure above.

Directions For Using Premium One-Step Formula No. 6

This formula requires no rinsing. Always use a specific brush for this formula that is not used with any other formula, just as with the other **Audio Intelligent Vinyl Solutions** formulas.

1. Carefully remove loose dust and debris with a soft brush, compressed air, or by simply rinsing with cool tap water and then patting the record dry with a cotton towel. Do not use a microfiber towel as it will produce lint that is small enough to enter the record groove..
2. Apply enough **Premium One-Step Formula No. 6** to completely cover the surface of the record. A little trial and error will help in determining just how much fluid should be applied.
3. Using a rounded- or blunt-bristle nylon brush (we recommend our **Listener Select Record Cleaning Brush**) or cloth pad brush, carefully spread the **Premium One-Step Formula No. 6** over the entire surface of the record. Add more fluid as to completely cover the surface of the record. If fluid sloshes over the edge of the record you have applied more than is necessary. This is most easily done while the record is spinning on a vacuum record cleaning machine.
4. Gently apply a very slight pressure with the brush to the surface of the record. **DO NOT APPLY HARD PRESSURE AS THIS CAN COMPACT DEBRIS INTO THE RECORD GROOVES, MAKING THE CLEANING PROCESS MORE DIFFICULT AND CAN CAUSE PERMANENT DAMAGE TO THE RECORD!** Continue brushing for 1 to 3 minutes, agitating the fluid on the record and allowing the enzymatic content of the formula to loosen and dissolve the contaminants on the record.

Directions For Using Premium Record Cleaner Formula No. 15

Premium Record Cleaner Formula No. 15 is designed for tough cleaning jobs, such as resale records and records with difficult to dissolve contaminants like tobacco tar. It is designed to be used as a pre-cleaner before using our 3-step cleaning system or our **Premium One-Step Formula No. 6** product. **Premium Record Cleaner Formula No. 15** can also be used as a first step with our **Ultra-Pure Water** product or our **Premium One-Step Formula No. 6** as a very effective 2-step cleaning system.

Premium Record Cleaner Formula No. 15 is safe for use on all records, including shellacs.

1. Carefully remove loose dust and debris with a soft brush, compressed air, or by simply rinsing with cool tap water and then patting the record dry with a cotton towel. Do not use a microfiber towel as it will produce lint that is small enough to enter the record groove.
2. Apply enough **Premium Record Cleaner Formula No. 15** to completely cover the surface of the record. A little trial and error will help in determining just how much fluid should be applied.
3. Using a rounded- or blunt-bristle nylon brush (we recommend our **Listener Select Record Cleaning Brush**) or cloth pad brush, carefully spread the **Premium Record Cleaner Formula No. 15** over the entire surface of the record. Add more fluid as necessary to completely cover the surface of the record. If fluid splashes over the edge of the record, you have applied more than is necessary. This is most easily done while the record is spinning on a vacuum record cleaning machine.
4. Gently apply a very slight pressure with the brush to the surface of the record. **DO NOT APPLY HARD PRESSURE AS THIS CAN COMPACT DEBRIS INTO THE RECORD GROOVES, MAKING THE CLEANING PROCESS MORE DIFFICULT AND CAN CAUSE PERMANENT DAMAGE TO THE RECORD!** Continue brushing for 1 to 3 minutes, agitating the fluid on the record and allowing the enzymatic content of the formula to loosen and dissolve the contaminants on the record.
5. For a final cleaning step, use the **Ultra-Pure Water** product or **Premium One-Step Formula No. 6** with a separate brush, following the procedure above.

Special Directions For Cleaning Without a Record Cleaning Machine

1. The record should be placed on a flat surface, preferably with a cork or rubber mat or soft, absorbent cloth beneath it.
2. Follow the instruction in the machine cleaning section for applying and brushing the fluid onto the record. Using the brush, work around the record following the grooves. This can be done in both directions for added effectiveness.
3. Repeat for each step when using the **Audio Intelligent Vinyl Solutions** 3-step record cleaning process. The **Premium One-Step Formula No. 6** requires only one step and does not require rinsing. **Premium Record Cleaner Formula No. 15**, followed by a second step with **Ultra-Pure Water**, is also effective for hand cleaning.
4. When the brushing process is completed, thoroughly dry the record using lint-free toweling, such as that available at photography supply shops or on the Internet. Cloth diapers also work well. Always work in the direction of the grooves, applying firm but not excessive pressure. Turn the cloth over frequently to avoid introducing the dissolved contaminants to the surface of the record.

Advanced Cleaning Procedures For New Records and Resale Records

New records can be some of the dirtiest because of environmental exposure during the pressing and packaging processes. If these records have a paper inner sleeve then the contamination can be even more profound. We have also seen instances where an excess of the additives in the record vinyl formula to aid in removing the record from the press and which preserves the record is present. This can cause dust to stick to the record, resulting 'pops' and 'clicks' that can be heard during playback. We have observed the results of these conditions through laboratory testing. These substances can be difficult to remove without damaging the record or complicating the cleaning process. Some products that are effective at removing them can deposit other contaminants that are difficult to remove, and some can damage the record.

Used resale records present another set of problems. After long periods of time, contaminants can build up on records and these contaminants can also become compacted into the grooves by playing the record while dirty. For proper sound reproduction, and to prevent damage to the record or to the stylus, this contamination should be removed.

Tobacco tar is also a common contaminant on used records. **Premium Record Cleaner Formula No. 15** is formulated to remove tobacco tar.

The directions detailed below will help insure that your records are safely and thoroughly cleaned and will give you a lifetime of enjoyment.

Recommended Pre-Soaking Method

Premium Record Cleaner Formula No. 15 is designed with presoaking and tough job record cleaning in mind, but both the **Enzymatic Formula** and the **Premium One-Step Formula No. 6** are excellent pre-soaking agents as well. The pre-soaking procedure detailed below is recommended for both new records and resale records that have proven difficult to clean. To pre-soak, apply sufficient **Premium Record Cleaner Formula No. 15, Enzymatic Formula** or **Premium One-Step Formula No. 6** to completely cover the surface of the record. Gently brush and agitate the fluid for 1 to 3 minutes. If desired, let the record stand with the fluid layer intact for an additional period of time not exceeding 5 minutes of total contact time and then remove by record cleaning machine vacuum or toweling described in the hand cleaning section. Add more fluid and spread it around the record should evaporation begin to occur during the pre-soaking process. **DO NOT ALLOW ANY FORMULA TO DRY ON THE RECORD SURFACE.** In some cases, it may be necessary to repeat this process 2 to 4 times to completely clean the record.

Here's why: Although the fluid quantity is sufficient to cover the surface of the record, the quantity of fluid is small. As contaminants break down, they can populate the fluid to the point of obstructing the effectiveness of the enzymatic content of the **Premium Record Cleaner Formula No. 15, Enzymatic,** and **Premium One-Step Formulas.** If this happens, the used fluid needs to be removed from the record and new fluid applied.

An analogy to this is washing your muddy hands in a small bowl of water. It will be necessary to repeat the process in order to get your hands clean because the water has become polluted. The theory behind this procedure is no more complicated than that and the pre-soaking procedure is based on extensive laboratory testing of record cleaning techniques and physical examination of the record under magnification. In all circumstances, enzymatic-based products such as **Audio Intelligent Vinyl Solutions** need time to break down and dissolve contaminants in order to be their most effective. They also need a layer of fluid for those dissolved contaminants to migrate into in order to be removed from the record effectively. Using a just a few drops of ANY fluid will do little more than remove the dust from a record. Another analogy that can be drawn is the fact that no one would wash a dirty dish with a few drops of soapy water. The principle is the same for cleaning records.

The good news is that once a record has been thoroughly cleaned it is reasonably easy to maintain in that condition. A thorough cleaning is recommended every 6 months or so; sooner if the record is handled and played frequently. A record that is maintained in clean condition will have very minimal 'pops' and 'clicks', will be true to the recording, and will continue to provide a lifetime of listening enjoyment when played on a properly adjusted and maintained turntable setup.

Additional Tips For Cleaning Your Records With Audio Intelligent Vinyl Solutions Products

1. Always store your **Audio Intelligent Vinyl Solutions** products in their original bottles with their caps securely closed and away from light and heat sources. The HDPE (high-density polyethylene) bottles are designed to preserve the fluids for several years.
2. Keep all **Audio Intelligent Vinyl Solutions** products away from children and pets.
3. Never mix any of the formulas together. They are each designed to perform a specific record cleaning task and mixing them will significantly lower their effectiveness. Also, never add any other ingredients, such as detergents, surfactants, or alcohol, to any of the formulas or dilute any of the ready-to-use formulas.
4. Always designate and use a separate brush for each formula, including the **Ultra-Pure Water** products. This prevents transfer of contaminants from one step to the next and prevents mixing of the formulas.
5. Rinse your brushes frequently using the **Ultra-Pure Water** product, reverse osmosis processed water, or distilled water to prevent the transfer of contaminants from one record to the next. Record cleaning machine vacuum pickup tubes and assemblies should also be rinsed frequently.
6. Never use the **Super Cleaner Formula** or the **Premium Archivist Formula** before the **Enzymatic Formula**.
7. The **Enzymatic, Super Cleaner,** and **Premium Archivist Formulas** are not single step products and should never be used alone. Neither should they be used with other brands of record cleaning products as formulary incompatibilities could result. None of these three formulas is a complete cleaning solution. The **Enzymatic Formula** should be followed by either the **Super Cleaner Formula** or the **Premium Archivist Formula** to provide a complete cleaning solution.
8. Please note that all **Audio Intelligent Vinyl Solutions** record cleaning products are composed of cleaning enzyme components and do not contain any non-botanical surfactants or detergents other than the small amount of Isopropyl alcohol in the **Super Cleaner Formula**.
9. Never use **Premium Record Cleaner Formula No. 15** by itself. It should always be followed by one of our 3-step cleaning systems, **Premium One-Step Formula No. 6,** or by **Ultra-Pure Water**.
10. We recommend that none of the **Audio Intelligent Vinyl Solutions** products be left in contact with the surface of the record for more than approximately 5 minutes without removal.
11. When hand cleaning, always use soft, lint-free cotton toweling or cloth diapers for drying the record. These products are

available in photography supply shops and can be found on the internet and in kitchen stores as well. Synthetic micro-fiber towels are NOT lint-free and will deposit small particles of lint on the record that are small enough to enter the record groove. Any loose cotton fibers are much larger and will not become lodged the record groove.

12. NEVER employ hard scrubbing when cleaning any record with any record cleaning product. Doing so can result in a record that is much more difficult to thoroughly clean and can cause permanent damage to the record.
13. Always check the stylus on your cartridge for a ball or glob of residue after playback of a record. IF YOU FIND ANYTHING OTHER THAN DUST OR LINT, YOUR RECORD IS NOT CLEAN. This is an indication that contaminants are present on your record or that a lubricant is present.
14. **PLEASE NOTE – Down With Dirty Enzymatic Record Cleaning Concentrate** and **Enzymatic Stylus Cleaning Formula** both come with separate instruction sheets, which can be downloaded on our website. **Ultra-Low Foaming Formula No. 27** and **Enzymatic Record Cleaning Concentrate For Ultrasonic Record Cleaning Machines** have their simple-to-use instructions printed on their labels.
15. Don't let cleaning your records consume you or your time. Don't forget that the purpose for cleaning your records is to enhance your listening enjoyment. Don't let cleaning records interfere with listening to them. Plan your time so that there is plenty of time for listening. This will help keep the work and time involved with cleaning your records from becoming a dreaded task, and one that you are prone to putting off or skipping altogether.

Warnings and Cautions

The **Super Cleaner Formula** contains a small quantity of laboratory grade Isopropanol. Isopropanol is flammable. However, the **Super Cleaner Formula** is not flammable and is exempt from D.O.T. 49CFR. To avoid any risk of injury, do not use the **Super Cleaner Formula** near open flame or fire, and avoid prolonged close exposure to its fumes.

Keep all **Audio Intelligent Vinyl Solutions Formulas** out of the reach of children and pets. Please read and follow all warnings and instructions on the individual product labels.

Audio Intelligent Vinyl Solutions products should not be ingested and prolonged contact with the skin should be avoided. Wash hands thoroughly after exposure to any of the **Audio Intelligent Vinyl Solutions** formulas.

If you get any of the formulas in your eyes or nose, seek medical attention immediately.

The **Super Cleaner Formula** is not recommended for use on non-vinyl records, such as shellac records. For these records, use the **Premium Archivist Formula** as the second step in the 3-step record cleaning process, or use the **Premium One-Step Formula No. 6**, or **Premium Record Cleaner Formula No. 15** with an **Ultra-Pure Water** rinse.

Only our **Enzymatic Record Cleaning Concentrate For Ultrasonic Record Cleaning Machines** is intended for use in ultrasonic record cleaning machines. Our other formulas should never be used in ultrasonic machines.

Audio Intelligent Vinyl Solutions products
are Manufactured and Distributed by

Osage

Audio Products, LLC

www.osageaudio.com • www.audiointelligent.com

573-696-3551

A home filled with music is a home filled with joy.

Quality Audio Products and Accessories

P.O. Box 232, Hallsville, MO 65255

(December 2024)